



Future Coat Technology

STRIP X HD GOLD PLUS

Strip X HD is capable to strip gold layer without the damage on the lower copper and nickel layer

Solution composition and operative conditions:

	Optimum	Range
Gold stripper	L/L 0.1	0.1-0.15
KCN	g/L 50	45-60
Temperature	°C 27	20-40
Strip X HD velocity (27°C)	μ/min 1.5	
Strip X HD bath	PVC liner tank or stainless steel tank	
Heating	stainless steel heating pipe	
Mixture	Cathode movement	
Ventilation	Necessary	

2. Preparation method

- (1) Clean gold-stripping bath completely, and fill pure water with ½ required volumes;
- (2) Add KCN in proportion to mix and dissolve;
- (3) Add gold-stripper with the required volume, to mix evenly.
- (4) Fill pure water to specified volume.

3. Maintenance

When the gold-stripping velocity is slow, gold stripper should be supplemented;

